

Machinery Mover

Owner's Manual



WARNING: Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Items#:DW-41

SAVE THESE INSTRUCTIONS

Thank you very much for choosing a Dawei™ product!

For future reference, please complete the owner's record below:

Serial Number/Lot Date Code:

Purchase Date:

Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This Dawei Steering Arm is designed for certain applications only. Hebei Dawei Hoisting Machinery Manufacturing Co., LTD is not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

For technical questions, please call 0086-0312-8151171.

Table of Contents

Intended Use	4
Technical Specifications	4
Important Safety Information	
Specific Operation Warnings	
Operating Instructions	
Maintenance	
Parts List	
Replacement Parts	
Limited Warranty	

Intended Use

This Dawei Steering Arm 41in L handle for easy operation of mover, suitable for item# CRA-6, CRA-8, CRA-12, CRA-18 Machinery Movers

Technical Specifications

Item#	Weight	Length
DW-41	4.74lb	41.73 in

Important Safety Information

AWARNING

- Read and understand all instructions. Failure to follow all instructions may result in serious injury or property damage.
- The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that could occur. Exercise common sense and caution when using this tool. Always be aware of the environment and ensure that the tool is used in a safe and responsible manner.
- Do not allow persons to operate or assemble the mover until they have read this manual and have developed a thorough understanding of how it works.
- Do not modify this Arm in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the product. There are specific applications for which the product was designed.
- Use the right tool for the job. DO NOT attempt to force small equipment to do the work of larger industrial equipment. There are certain applications for which this equipment was designed. It will be safer and do a better job at the capacity for which it was intended. DO NOT use this equipment for a purpose for which it was not intended.
- Industrial or commercial applications must follow OSHA requirements.

MWARNING

 This product may contain chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

MWARNING

WORK AREA SAFETY

- Inspect the work area before each use. Keep work area clean, dry, free of clutter, and well lit.
 Cluttered, wet, or dark work areas can result in injury. Using the mover in confined work areas may put you dangerously close to other cutting tools and rotating parts.
- Keep children and bystanders away from the work area while operating the mover. Do not allow children to handle it.

•

MWARNING

PERSONAL SAFETY

- Stay alert, watch what you are doing, and use common sense when operating the mover. Do not use the mover while you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating the tool may result in serious personal injury.
- Dress properly. Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts. Air vents on the tool often cover moving parts and should be avoided.
- Wear the proper personal protective equipment when necessary. Use ANSI Z87.1 compliant safety goggles (not safety glasses) with side shields, or when needed, a face shield. Use a dust mask in dusty work conditions. Also use non-skid safety shoes, hardhat, gloves, dust collection systems, and hearing protection when appropriate. This applies to all persons in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Secure the work with clamps or a vise instead of your hand when practical. This safety precaution allows for proper tool operation using both hands.

ACAUTION

MOVER USE AND CARE

- Do not force the steering arm. Products do a better job and are safer when used in the manner for which they are designed. Plan your work, and use the correct product for the job.
- Check for damaged parts before each use. Carefully check that the steering arm will operate
 properly and perform its intended function. Replace damaged or worn parts immediately. Never
 operate the steering arm with a damaged part.
- Store the steering arm when it is not in use. Store it in a dry, secure place out of the reach of children. Inspect the steering arm for good working condition prior to storage and before re-use.
- Use only mover that are recommended by the manufacturer for use with your steering arm. Accessories that may be suitable for one product may create a risk of injury when used with another tool. Never use an accessory that has a lower operating speed or operating pressure than the tool itself.
- Keep guards in place and in working order. Never operate the mover without the guards in place.

Specific Operation Warnings


MWARNING

- Study, understand, and follow all instructions before operating this device.
- Do not exceed the rated capacity.
- Use only on hard, level surfaces.
- When loading the cargo, load at a vertical angle to prevent a rollover.
- Do not use steering arm too hard
- Install the steering arm in the center of the mover connection
- Do not alter the steering arm.
- Failure to follow these warnings may result in personal injury and/or property damage.

Operating Instructions

When using this product, please follow these steps:

- 1. Install the steering arm in the center of the applicable mover connection.
- 2. Choose the appropriate cargo weight according to the mover's capacity.
- 3. Place the mover in a place where it's easy to move the cargo onto the mover.
- 4. Lift and slowly lower the cargo onto the mover. Make sure the cargo stays steadily on the mover and push the cargo to move the mover.



Suitable for item# CRA-6, CRA-8, CRA-12, CRA-18 Machinery Movers, is sold separately.

Maintenance

Maintain the steering arm by adopting a program of conscientious repair and maintenance. It is recommended that the general condition of any tool be examined before it is used. Keep your tool in good repair. Keep all cutting tools sharp and clean.

Parts List

Part Number	Part Description	Quantity
1	Upper Steering Arm body	1
2	Lower Steering Arm body	1
3	Connecting bolt	1
4	Connecting nut	1

Replacement Parts

For replacement parts and technical questions, please call Customer Service at **0086-0312-8151171**. Not all product components are available for replacement. The illustrations provided are a convenient reference to the location and position of parts in the assembly sequence.

When ordering parts, the following information will be required: item description, item model number, item serial number/item lot date code, and the replacement part reference number.

The distributor reserves the rights to make design changes and or improvements to product lines and manuals without notice.

Limited Warranty

Hebei Dawei Hoisting Machinery Manufacturing Co., LTD("We" or ""Us") warrants to the original purchaser only ("You" or "Your") that the Dawei product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of <u>one year from date</u> of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product or product component without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

Obligations of Purchaser

You must retain Your product purchase receipt to verify date of purchase and that You are the original purchaser. To make a warranty claim, contact Us at 0086-0312-8151171, identify the product by make and model number, and follow the claim instructions that will be provided. The product and the purchase

receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs or costs related to Your return visit to a retail store.

Remedy Limits

Product replacement or a refund of the purchase price is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for: service or labor charges or damage to Your property incurred in removing or replacing the product; any damages, including, without limitation, damages to tangible personal property or personal injury, related to Your improper use, installation, or maintenance of the product or product component; or any indirect, incidental or consequential damages of any kind for any reason.

Assumption of Risk

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.



Distributed by:

Hebei Dawei Hoisting Machinery Manufacturing Co., LTD

Donglv Industrial Park, Qingyuan District, Baoding City, Hebei province 071100

Made in China